





Replacement Parts List


304-318

VI 3013, VI 4013


WHEN SELECTING AND ORDERING PARTS, ALWAYS REFER TO SERIAL NUMBER ON NAMEPLATE



ITEM NO.	NO. REQ.	DESCRIPTION	3013	3013	4013	4013	
			FRAME H, J OR K	FRAME L, M OR N	FRAME H, J OR K	FRAME L, M OR N	
1	1	IMPELLER (CI)	953-1120RP	953-1121RP	953-1136RP	953-1137RP	
1	1	IMPELLER (BRZ)	953-1122RP	953-1123RP	953-1138RP	953-1139RP	
2	1	CASING (125#)(W/WR OPT)	953-1126RP	953-1126RP	953-1142RP	953-1142RP	
2	1	CASING (250#)(W/WR OPT)	953-1127RP	953-1127RP	953-1143RP	953-1143RP	
2	1	CASING (125#)(NO WR STD)	953-1469RP	953-1469RP	953-1475RP	953-1475RP	
2	1	CASING (250#)(NO WR STD)	953-1471RP	953-1471RP	953-1477RP	953-1477RP	
3	1(W/R)	WEAR RING (BRZ) (OPT)	LE5689-12RP	LE5689-12RP	953-1145RP	953-1145RP	
5	1	DOWDY WASHER	951-2578RP	951-2579RP	951-2578RP	951-2579RP	
6	1	IMPELLER BOLT	HARDWARE				
7	1	IMPELLER KEY	HARDWARE				
8	1	IMPELLER WASHER	953-828RP	953-829RP	953-829RP	953-829RP	
9	1	GASKET (CASING)	LE5316-16RP	LE5316-16RP	LE5316-16RP	LE5316-16RP	
14	16	CASING BOLT	HARDWARE				
18	5	PIPE PLUG	HARDWARE				
26	16	CASING WASHER	HARDWARE				
29	1	IMPELLER GASKET	953-830RP	953-759RP	953-830RP	953-759RP	



ITEM NO.	NO. REQ.	DESCRIPTION	MOTOR FRAME				MODEL NO
			H OR J	K	L	M,N OR R	
4	1	COVER	953-1133RP	953-1134RP	953-912RP	953-916RP	3013 ↓
9	1	GASKET (CASING)	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1	
20	4	MOTOR BOLT	← HARDWARE →				
27	4	MOTOR WASHER	← HARDWARE →				
35	1	TUBE KIT	953-1547RP	953-1547RP	953-1547RP	953-1547RP	
4	1	COVER	-----	953-1135RP	953-1146RP	953-1147RP	4013 ↓
9	1	GASKET (CASING)	-----	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1	
20	4	MOTOR BOLT	← HARDWARE →				
27	4	MOTOR WASHER	← HARDWARE →				
35	1	TUBE KIT	-----	953-1547RP	953-1547RP	953-1547RP	
4	1	COVER	-----	953-1175RP	953-914RP	953-918RP	6013 ↓
9	1	GASKET (CASING)	-----	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1	
20	4	MOTOR BOLT	← HARDWARE →				
27	4	MOTOR WASHER	← HARDWARE →				
35	1	TUBE KIT	-----	953-1547RP	953-1547RP	953-1547RP	
4	1	COVER	-----	-----	953-915RP	953-919RP	8013 ↓
9	1	GASKET (CASING)	-----	-----	SEE PAGE 1	SEE PAGE 1	
20	4	MOTOR BOLT	← HARDWARE →				
27	4	MOTOR WASHER	← HARDWARE →				
35	1	TUBE KIT	-----	-----	953-1547RP	953-1547RP	



PUMP MODELS

ITEM NO.	NO. REQ.	DESCRIPTION	MOTOR FRAME		MOTOR FRAME	
			H, J OR K	L,M,N OR R	H, J OR K	L,M,N OR R
			MECHANICAL DES. A OR C (125#)		MECHANICAL DES. B OR D (250#)	
9	1	GASKET (CASING)	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1	SEE PAGE 1
10	1	SLEEVE (SS)	951-1118	951-1170	951-1118	951-1170
10	1	SLEEVE (BRZ)	951-1119	951-1171	951-1119	951-1171
11	1	SEAL (TYPE B)	951-3157RP	951-3158RP	951-3766RP	951-5158RP
11	1	SEAL (TYPE D)	951-3159RP	951-3160RP	951-3781RP	951-5159RP
11	1	SEAL (TYPE E)	951-3161RP	951-3162RP	951-3782RP	951-5160RP
12	1	SLEEVE GASKET	953-830RP	951-3042RP	953-830RP	951-3042RP
22	1	DEFLECTOR	LE2000-11RP	LE1569-11RP	LE2000-11RP	LE1569-11RP
40	1	SEAL KIT (TYPE B) SS	953-1549-1RP	953-1549-4RP	953-1549-7RP	953-1549-10RP
40	1	SEAL KIT (TYPE B) BRZ	953-1549-1BRP	953-1549-4BRP	953-1549-7BRP	953-1549-10BRP
40	1	SEAL KIT (TYPE D) SS	953-1549-2RP	953-1549-5RP	953-1549-8RP	953-1549-11RP
40	1	SEAL KIT (TYPE D) BRZ	953-1549-2BRP	953-1549-5BRP	953-1549-8BRP	953-1549-11BRP
40	1	SEAL KIT (TYPE E) SS	953-1549-3RP	953-1549-6RP	953-1549-9RP	953-1549-12RP
40	1	SEAL KIT (TYPE E) BRZ	953-1549-3BRP	953-1549-6BRP	953-1549-9BRP	953-1549-12BRP

Do it Once. Do it Right.®

TACO INC., 1160 Cranston Street, Cranston, RI 02920 Telephone: (401) 942-8000 Fax: 942-2360
TACO (Canada), Ltd., 6180 Ordan Drive, Mississauga, Ontario L5T 2B3 Telephone: (905) 564-9422 Fax: (905) 564-9436
 Visit our website at: www.taco-hvac.com

Printed in USA
 Copyright 2007
 TACO, Inc.