



102-579

LeakBreaker®

Instruction Sheet Troubleshooting Guide Addendum

SUPERSEDES: NEW

EFFECTIVE: January 1, 2024

Plant ID No. 001-5069

LED STATUS POWER	LED STATUS BATTERY ONLY	INDICATES	POSSIBLE CAUSE	POSSIBLE SOLUTION	AUDIBLE ALARM
Solid Red with 5 red blinks	Solid Dim Red with 5 red blinks	Startup test issue	Valve closed, couldn't run startup test	If valve is intended to be closed push close button to clear notification. Otherwise push the manual open button. Once open the LeakBreaker will automatically run a test cycle in approx..... 30 seconds	Chirp every 60 seconds
			Valve stuck open, couldn't run startup test	Cycle the valve closed then open a few times using the manual buttons to free up the valve. If the valve is still stuck open or sends a valve error on the next exercise cycle the unit will need to be replaced.	

