


Replacement Parts List

Load Match Parts

104-126

Effective: January 5, 2022

Supersedes: NEW



L0205-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0205-B5CI1-FHAN	007-003RP	007-007RP	008-054RP	003-007RP	006-047RP	
L0205-B6BI2-C5AN	007-003RP	NA	008-054RP	003-001RP	006-047RP	
L0205-B6BV2-C7AN	007-003RP	NA	003-004RP	003-001RP	006-047RP	
L0205-B6CI2-FHAN	007-003RP	007-007RP	008-054RP	003-007RP	006-047RP	
L0205-R6BI1-C5AN	007-003RP	NA	007-046RP	Contact Eng	006-047RP	
L0205-R6BI1-C7AN	007-003RP	NA	007-046RP	Contact Eng	006-047RP	
L0205-Y6BI1-C5AN	007-003RP	NA	008-054RP	003-001RP	006-047RP	
L0205-Y6BI1-C7AN	007-003RP	NA	008-054RP	003-001RP	006-047RP	
L0205-Y6BV1-C5AN	007-003RP	NA	003-004RP	003-001RP	006-047RP	
L0205-Y6BV1-C7AN	007-003RP	NA	003-004RP	003-001RP	006-047RP	
L0205-Y6CF1-FHAN	007-003RP	007-007RP	003-008RP	003-007RP	006-047RP	
L0205-Y6CI1-FHAN	007-003RP	007-007RP	008-054RP	003-007RP	006-047RP	
L0205-Y6CV1-FHAN	007-003RP	007-007RP	003-004RP	003-007RP	006-047RP	
L0205-Y6CX1-FHA1	007-003RP	007-007RP	005-029RP	003-007RP	006-047RP	
L0205-Y6CX1-FHAN	007-003RP	007-007RP	005-025RP	003-007RP	006-047RP	
L0205-Y6SS1-N7AN	007-003RP	NA	007-002RP	003-001RP	NA	

L0410-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0410-B5CI1-FHAN	007-003RP	007-007RP	007-002RP	005-019RP	006-0047RP	
L0410-B5CI2-FHAN	007-003RP	007-007RP	008-054RP	005-019RP	006-0047RP	
L0410-B6BI1-C5AN	007-003RP	NA	007-002RP	005-020RP	006-047RP	
L0410-B6BI1-C7AN	007-003RP	NA	007-002RP	005-020RP	006-047RP	
L0410-B6BI2-C5AN	007-003RP	NA	008-054RP	005-020RP	006-047RP	
L0410-B6BI2-C7AN	007-003RP	NA	008-054RP	005-020RP	006-047RP	
L0410-B6BS1-C7QN	007-003RP	NA	007-002RP	005-020RP	NA	
L0410-B6CI1-FHAN	007-003RP	007-007RP	007-002RP	005-019RP	006-047RP	
L0410-B6CI2-FHAN	007-003RP	007-007RP	008-054RP	005-019RP	006-047RP	
L0410-B6CS1-FHJN	007-003RP	007-007RP	007-002RP	005-019RP	NA	
L0410-B6JI2-FHAN	007-003RP	007-007RP	008-054RP	005-020RP	006-047RP	
L0410-B6JS2-FHJN	007-003RP	007-007RP	008-054RP	005-020RP	NA	
L0410-R6BI1-C5AN	007-003RP	NA	007-046RP	007-045RP	006-047RP	
L0410-R6BI1-C7AN	007-003RP	NA	007-046RP	007-045RP	006-047RP	
L0410-R6BS1-S7NN	007-003RP	NA	007-046RP	007-045RP	NA	
L0410-R6CI1-FHAN	007-003RP	007-007RP	007-046RP	007-042RP	006-047RP	
L0410-R6JI1-FHAN	007-003RP	007-007RP	007-046RP	007-045RP	006-047RP	
L0410-Y6BF1-C7AN	007-003RP	NA	003-008RP	005-020RP	006-047RP	
L0410-Y6BI1-C5AN	007-003RP	NA	007-002RP	005-020RP	006-047RP	
L0410-Y6BI1-C7AN	007-003RP	NA	007-002RP	005-020RP	006-047RP	

L0410-Y6BI1-C7JN	007-003RP	NA	007-002RP	005-020RP	006-047RP	
L0410-Y6BS1-S7AN	007-003RP	NA	007-002RP	005-020RP	NA	
L0410-Y6BS1-S7NN	007-003RP	NA	007-002RP	005-020RP	NA	
L0410-Y6BV1-C5AN	007-003RP	NA	003-004RP	005-020RP	006-047RP	
L0410-Y6BV1-C7AN	007-003RP	NA	003-004RP	005-020RP	006-047RP	
L0410-Y6BX1-C7A1	007-003RP	NA	005-029RP	005-020RP	006-047RP	
L0410-Y6BX1-C7AN	007-003RP	NA	005-025RP	005-020RP	006-047RP	
L0410-Y6BZ1-N7A1	007-003RP	NA	005-029RP	005-020RP	NA	
L0410-Y6BZ1-N7AN	007-003RP	NA	005-025RP	005-020RP	NA	
L0410-Y6CD1-FHAN	007-003RP	007-007RP	003-004RP	005-019RP	NA	
L0410-Y6CF1-FHAN	007-003RP	007-007RP	003-008RP	005-019RP	006-047RP	
L0410-Y6CI1-FHAN	007-003RP	007-007RP	007-002RP	005-019RP	006-047RP	
L0410-Y6CV1-FHAN	007-003RP	007-007RP	003-004RP	005-019RP	006-047RP	
L0410-Y6CX1-FHAN	007-003RP	007-007RP	005-025RP	005-019RP	006-047RP	
L0410-Y6SZ1-N7AN	007-003RP	NA	005-029RP	005-020RP	NA	

L0435-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0435-B5CI1-FHAN	009-005RP	007-007RP	0010-012RP	009-021RP	009-033RP	
L0435-B6BS1-FHQN	009-005RP	007-007RP	0010-012RP	009-022RP	NA	
L0435-B6CI1-FHAN	009-005RP	007-007RP	0010-012RP	009-021RP	009-033RP	
L0435-B6CS1-FHEN	009-005RP	007-007RP	0010-012RP	009-021RP	NA	
L0435-B6CS1-FHJN	009-005RP	007-007RP	0010-012RP	009-021RP	NA	
L0435-B6JS1-FHEN	009-005RP	007-007RP	0010-012RP	009-022RP	NA	
L0435-B6SI1-FHAN	009-005RP	007-007RP	0010-012RP	009-022RP	009-033RP	
L0435-R6CI1-FHAN	009-005RP	007-007RP	0010-012RP	009-040RP	009-033RP	
L0435-R6CI2-FHAN	009-005RP	007-007RP	0010-012RP	009-041RP	009-033RP	
L0435-R6JS1-FHEN	009-005RP	007-007RP	0010-012RP	009-039RP	NA	
L0435-Y6CD1-FHAN	009-005RP	007-007RP	009-029RP	009-021RP	009-033RP	
L0435-Y6CF1-FHAN	009-005RP	007-007RP	009-035RP	009-021RP	009-033RP	
L0435-Y6CI1-FHAN	009-005RP	007-007RP	009-018RP	009-021RP	009-033RP	
L0435-Y6CS1-FHAN	009-005RP	007-007RP	009-018RP	009-021RP	NA	
L0435-Y6CV1-FHAN	009-005RP	007-007RP	009-029RP	009-021RP	009-033RP	
L0435-Y6CX1-FHAN	009-005RP	007-007RP	009-043RP	009-021RP	009-033RP	
L0435-Y6SI1-FHAN	009-005RP	007-007RP	009-018RP	009-022RP	009-033RP	

L0515-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0515-B5CI1-FHAN	008-005RP	007-007RP	007-046RP	008-044RP	006-047RP	
L0515-B6BI1-C7AN	008-005RP	NA	007-046RP	008-045RP	006-047RP	
L0515-B6BS1-C7AN	008-005RP	NA	007-046RP	008-045RP	006-047RP	
L0515-B6BS1-C7QN	008-005RP	NA	007-046RP	008-045RP	NA	
L0515-B6CI1-FHA1	008-005RP	007-007RP	007-046RP	008-044RP	0010-025RP	
L0515-B6CI1-FHAN	008-005RP	007-007RP	007-046RP	008-044RP	006-047RP	
L0515-B6CS1-FHJN	008-005RP	007-007RP	007-046RP	008-044RP	NA	
L0515-B6JI1-FHA1	008-005RP	007-007RP	007-046RP	008-045RP	0010-025RP	
L0515-B6JI1-FHAN	008-005RP	007-007RP	007-046RP	008-045RP	006-047RP	
L0515-B6JS1-FHJN	008-005RP	007-007RP	007-046RP	008-045RP	NA	
L0515-B6SI1-FHAN	008-005RP	007-007RP	007-046RP	008-045RP	006-047RP	
L0515-R6BI1-C7AN	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6BI1-C7DN	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6BI1-C7FN	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6BI1-C7KN	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6BI1-C7KP	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6BS1-C7AN	008-005RP	007-007RP	008-054RP	008-058RP	006-047RP	
L0515-R6CI1-FHA1	008-005RP	007-007RP	008-054RP	008-057RP	0010-025RP	
L0515-R6CI1-FHAN	008-005RP	007-007RP	008-054RP	008-057RP	006-047RP	
L0515-R6CS1-FHAN	008-005RP	007-007RP	008-054RP	008-057RP	NA	
L0515-R6JS1-FHJN	008-005RP	007-007RP	008-054RP	008-058RP	NA	
L0515-Y6BI1-C7AN	008-005RP	NA	007-002RP	008-045RP	006-047RP	
L0515-Y6BI1-C7JN	008-005RP	NA	007-002RP	008-045RP	006-047RP	
L0515-Y6BS1-C7AN	008-005RP	NA	007-002RP	008-045RP	NA	

L0515-Y6BS1-C7BN	008-005RP	NA	007-002RP	008-045RP	NA	
L0515-Y6BV1-C7AN	008-005RP		003-004RP	008-045RP	006-047RP	
L0515-Y6BX1-C7AN	008-005RP	NA	005-025RP	008-045RP	006-047RP	
L0515-Y6CD1-FHAN	008-005RP	007-007RP	003-004RP	008-044RP	NA	
L0515-Y6CF1-FHA1	008-005RP	007-007RP	003-008RP	008-044RP	0010-025RP	
L0515-Y6CF1-FHAN	008-005RP	007-007RP	003-008RP	008-044RP	006-047RP	
L0515-Y6CI1-FHA1	008-005RP	007-007RP	007-002RP	008-044RP	0010-025RP	
L0515-Y6CI1-FHAN	008-005RP	007-007RP	007-002RP	008-044RP	006-047RP	
L0515-Y6CV1-FHA1	008-005RP	007-007RP	003-004RP	008-044RP	0010-025RP	
L0515-Y6CV1-FHAN	008-005RP	007-007RP	003-004RP	008-044RP	006-047RP	
L0515-Y6CX1-FHA1	008-005RP	007-007RP	005-029RP	008-044RP	006-047RP	
L0515-Y6CX1-FHA2	008-005RP	007-007RP	005-029RP	008-044RP	0010-025RP	
L0515-Y6CX1-FHAN	008-005RP	007-007RP	005-025RP	008-044RP	006-047RP	
L0515-Y6JI1-FHAN	008-005RP	007-007RP	007-002RP	008-045RP	006-047RP	
L0515-Y6SD1-FHAN	008-005RP	007-007RP	003-004RP	008-045RP	NA	
L0515-Y6SI1-FHAN	008-005RP	007-007RP	007-002RP	008-045RP	0010-025RP	

L0609-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0609-B5CI1-FHAN	008-005RP	007-007RP	007-002RP	005-019RP	005-031RP	
L0609-B6CI1-FHA1	008-005RP	007-007RP	007-002RP	005-019RP	005-031RP	
L0609-B6CI1-FHAN	008-005RP	007-007RP	007-002RP	005-019RP	006-047RP	
L0609-B6CI2-FHAN	008-005RP	007-007RP	008-054RP	005-019RP	005-031RP	
L0609-R6CI1-FHAN	008-005RP	007-007RP	007-046RP	007-042RP	005-031RP	
L0609-Y6CD1-FHA1	008-005RP	007-007RP	003-004RP	005-019RP	NA	
L0609-Y6CF1-FHA1	008-005RP	007-007RP	003-008RP	005-019RP	005-031RP	
L0609-Y6CI1-FHA1	008-005RP	007-007RP	007-002RP	005-019RP	005-031RP	
L0609-Y6CI1-FHAN	008-005RP	007-007RP	007-002RP	005-019RP	006-047RP	
L0609-Y6CV1-FHA1	008-005RP	007-007RP	003-004RP	005-019RP	005-031RP	
L0609-Y6CV1-FHAN	008-005RP	007-007RP	003-004RP	005-019RP	006-047RP	
L0609-Y6CX1-FHA1	008-005RP	007-007RP	005-029RP	005-019RP	005-031RP	
L0609-Y6CX1-FHAN	008-005RP	007-007RP	005-029RP	005-019RP	006-047RP	
L0609-Y6SI1-FHAN	008-005RP	007-007RP	007-002RP	005-020RP	005-031RP	

L0710-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L0710-B5BS1-FVAN	008-005RP	007-007RP	007-046RP	007-045RP	NA	
L0710-B5SS1-FVA1	008-005RP	007-007RP	007-046RP	007-045RP	NA	
L0710-B6CI1-FHA1	008-005RP	007-007RP	007-046RP	007-042RP	005-031RP	
L0710-B6CI1-FHAN	008-005RP	007-007RP	007-046RP	007-042RP	006-047RP	
L0710-B6JS1-FVAN	008-005RP	007-007RP	007-046RP	007-045RP	NA	
L0710-B6SI1-FVAN	008-005RP	007-007RP	007-046RP	007-045RP	0010-025RP	
L0710-R6CI1-FHA1	008-005RP	007-007RP	008-054RP	007-061RP	005-031RP	
L0710-R6CI1-FHAN	008-005RP	007-007RP	008-054RP	007-061RP	006-047RP	
L0710-Y6CD1-FHA1	008-005RP	007-007RP	003-004RP	007-042RP	NA	
L0710-Y6CF1-FHA1	008-005RP	007-007RP	003-008RP	007-042RP	005-031RP	
L0710-Y6CF1-FHAN	008-005RP	007-007RP	003-008RP	007-042RP	006-047RP	
L0710-Y6CI1-FHA1	008-005RP	007-007RP	007-002RP	007-042RP	005-031RP	
L0710-Y6CI1-FHAN	008-005RP	007-007RP	007-002RP	007-042RP	006-047RP	
L0710-Y6CV1-FHA1	008-005RP	007-007RP	003-004RP	007-042RP	005-031RP	
L0710-Y6CV1-FHAN	008-005RP	007-007RP	003-004RP	007-042RP	006-047RP	
L0710-Y6CX1-FHA1	008-005RP	007-007RP	005-029RP	007-042RP	005-031RP	
L0710-Y6CX1-FHAN	008-005RP	007-007RP	005-025RP	007-042RP	006-047RP	
L0710-Y6JS1-FVAN	008-005RP	007-007RP	007-002RP	007-045RP	NA	
L0710-Y6SI1-FVA1	008-005RP	007-007RP	007-002RP	007-045RP	0010-025RP	
L0710-Y6SI1-FVAN	008-005RP	007-007RP	007-002RP	007-045RP	0010-025RP	
L0710-Y6SS1-FVA1	008-005RP	007-007RP	007-002RP	007-045RP	0010-025RP	

L1034-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay

L1034-B6CI1-FHA1	009-005RP	007-007RP	0013-003RP	0013-007RP	0012-021RP	
L1034-B6CI1-FHAN	009-005RP	007-007RP	0013-003RP	0013-007RP	0011-023RP	
L1034-B6CI2-FHAN	009-005RP	007-007RP	0013-028RP	0013-007RP	0012-021RP	
L1034-B6CS1-FHAN	009-005RP	007-007RP	0013-003RP	0013-007RP	N/A	
L1034-B6JI1-FHA2	009-005RP	007-007RP	0013-003RP	0013-008RP	0012-021RP	
L1034-B6JI2-FHA2	009-005RP	007-007RP	0013-028RP	0013-008RP	0012-021RP	
L1034-B6JS1-FHAN	009-005RP	007-007RP	0013-003RP	0013-008RP	NA	
L1034-B6SI2-FHAN	009-005RP	007-007RP	0013-028RP	0013-007RP	0012-021RP	
L1034-R6CI1-FHAN	009-005RP	007-007RP	0013-003RP	0013-024RP	0012-021RP	
L1034-R6CI2-FHAN	009-005RP	007-007RP	0013-003RP	0013-007RP	0012-021RP	
L1034-R6JI1-FHA2	009-005RP	007-007RP	0013-003RP	0013-025RP	0012-021RP	
L1034-R6JI2-FHA2	009-005RP	007-007RP	0013-003RP	0013-008RP	0012-021RP	
L1034-R6SI2-FHAN	009-005RP	007-007RP	0013-003RP	0013-007RP	0012-021RP	
L1034-Y6BI1-FHAN	009-005RP	007-007RP	0013-004RP	0013-008RP	0011-018RP	
L1034-Y6CD1-FHA1						
L1034-Y6CF1-FHA1	009-005RP	007-007RP	0013-016RP	0013-007RP	0012-021RP	
L1034-Y6CI1-FHA1	009-005RP	007-007RP	0013-004RP	0013-007RP	0012-021RP	
L1034-Y6CI1-FHAN	009-005RP	007-007RP	0013-004RP	0013-007RP	0011-018RP	
L1034-Y6CS1-FHAN	009-005RP	007-007RP	0013-004RP	0013-007RP	NA	
L1034-Y6CV1-FHA1	009-005RP	007-007RP	0013-015RP	0013-007RP	0012-021RP	
L1034-Y6CV1-FHAN	009-005RP	007-007RP	0013-015RP	0013-007RP	0011-018RP	
L1034-Y6CX1-FHA1	009-005RP	007-007RP	0013-018RP	0013-007RP	0012-021RP	
L1034-Y6SI1-FHAN	009-005RP	007-007RP	0013-004RP	0013-008RP	0012-021RP	
L1034-Y6SS1-FHAN	009-005RP	007-007RP	0013-004RP	0013-008RP	NA	

L1111-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L1111-B5CI1-FHAN	0010-008RP	007-007RP	0010-012RP	0010-021RP	005-031RP	
L1111-B5CI1-FVAN	0010-008RP	007-007RP	0010-012RP	0010-021RP	0012-021RP	
L1111-B6CI1-FHAN	0010-008RP	007-007RP	0010-012RP	0010-021RP	005-031RP	
L1111-B6CI1-FVAN	0010-008RP	007-007RP	0010-012RP	0010-021RP	0012-021RP	
L1111-R6CI2-FVAN	0010-008RP	007-007RP	0012-012RP	0010-035RP	0012-021RP	
L1111-Y6CD1-FVAN	0010-008RP	007-007RP	009-029RP	0010-021RP	NA	
L1111-Y6CF1-FVAN	0010-008RP	007-007RP	009-035RP	0010-021RP	0012-021RP	
L1111-Y6CI1-FHAN	0010-008RP	007-007RP	009-018RP	0010-021RP	005-031RP	
L1111-Y6CI1-FVAN	0010-008RP	007-007RP	009-018RP	0010-021RP	0012-021RP	
L1111-Y6CS1-FVAN	0010-008RP	007-007RP	009-018RP	0010-021RP	0012-021RP	
L1111-Y6CV1-FHAN	0010-008RP	007-007RP	009-029RP	0010-021RP	005-031RP	
L1111-Y6CV1-FVAN	0010-008RP	007-007RP	009-029RP	0010-021RP	0012-021RP	
L1111-Y6CX1-FVAN	0010-008RP	007-007RP	009-034RP	0010-021RP	0012-021RP	
L1111-Y6SI1-FVAN	0010-008RP	007-007RP	009-018RP	0010-022RP	0012-021RP	
L1111-Y6SS1-FVAN	0010-008RP	007-007RP	009-018RP	0010-022RP	NA	

L1121-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L1121-B5CI1-FHA1	009-005RP	007-007RP	0010-012RP	0014-004RP	0012-021RP	
L1121-B5CI1-FHAN	009-005RP	007-007RP	009-018RP	0014-004RP	0012-021RP	
L1121-B5SI1-FHAN	009-005RP	007-007RP	0010-012RP	0014-003RP	0012-021RP	
L1121-B6CI1-FHA1	009-005RP	007-007RP	0010-012RP	0014-004RP	0012-021RP	
L1121-B6CI1-FHAN	009-005RP	007-007RP	009-018RP	0014-004RP	0012-021RP	
L1121-B6CS1-FHKN	009-005RP	007-007RP	009-018RP	0014-004RP	NA	
L1121-B6JI1-FHA1	009-005RP	007-007RP	0010-012RP	0014-003RP	0012-021RP	
L1121-B6JI1-FHA2	009-005RP	007-007RP	0010-012RP	0014-003RP	0012-021RP	
L1121-B6JS1-FHAN	009-005RP	007-007RP	0010-0012RP	0014-003RP	NA	
L1121-B6SI1-FHAN	009-005RP	007-007RP	0010-012RP	0014-003RP	0012-021RP	
L1121-R6CI1-FHAN	009-005RP	007-007RP	0010-012RP	0014-011RP	0012-021RP	
L1121-R6CI2-FHAN	009-005RP	007-007RP	0010-012RP	0014-014RP	0012-021RP	
L1121-R6JI1-FHA2	009-005RP	007-007RP	0010-012RP	0014-012RP	0012-021RP	
L1121-R6JI2-FHA2	009-005RP	007-007RP	0010-012RP	0014-013RP	0012-021RP	
L1121-R6SI2-FHAN	009-005RP	007-007RP	0010-012RP	0014-013RP	0012-021RP	
L1121-Y6BI1-FHAN	009-005RP	007-007RP	009-018RP	0014-003RP	0011-018RP	
L1121-Y6CD1-FHA1						

L1121-Y6CI1-FHA1	009-005RP	007-007RP	009-018RP	0014-004RP	0012-021RP	
L1121-Y6CI1-FHAN	009-005RP	007-007RP	009-018RP	0014-004RP	0012-021RP	
L1121-Y6CS1-FHAN	009-005RP	007-007RP	009-018RP	0014-004RP	NA	
L1121-Y6CV1-FHA1	009-005RP	007-007RP	009-029RP	0014-004RP	0012-021RP	
L1121-Y6CV1-FHAN	009-005RP	007-007RP	009-029RP	0014-004RP	0012-021RP	
L1121-Y6CX1-FHA1	009-005RP	007-007RP	009-034RP	0014-004RP	0012-021RP	
L1121-Y6CX1-FHAN	009-005RP	007-007RP	009-024RP	0014-004RP	0012-021RP	
L1121-Y6JI1-FHA2	009-005RP	007-007RP	009-018RP	0014-003RP	0012-021RP	
L1121-Y6SI1-FHAN	009-005RP	007-007RP	009-018RP	0014-003RP	0012-021RP	
L1121-Y6SS1-FHAN	009-005RP	007-007RP	009-018RP	0014-003RP		

L1130-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L1130-B6BS1-FHQN	009-005RP	007-007RP	0010-012RP	0011-010RP	NA	
L1130-B6CI1-FHA1	009-005RP	007-007RP	0010-012RP	0011-009RP	0012-021RP	
L1130-B6CI1-FHAN	009-005RP	007-007RP	0010-012RP	0011-009RP	0011-023RP	
L1130-B6CS1-FHEN	009-005RP	007-007RP	0010-012RP	0011-009RP	NA	
L1130-B6JI1-FHA1	009-005RP	007-007RP	0010-012RP	0011-010RP	0012-021RP	
L1130-B6JI1-FHA2	009-005RP	007-007RP	0010-012RP	0011-010RP	0012-021RP	
L1130-B6JS1-FHEN	009-005RP	007-007RP	0010-012RP	0011-010RP	NA	
L1130-R6CI1-FHAN	009-005RP	007-007RP	0010-012RP	0011-026RP	0012-021RP	
L1130-R6CI2-FHAN	009-005RP	007-007RP	0010-012RP	0013-007RP	0012-021RP	
L1130-R6CS1-FHEN	009-005RP	007-007RP	0010-012RP	0011-026RP	NA	
L1130-R6J12-FHA2	009-005RP	007-007RP	0010-012RP	0013-008RP	0012-021RP	
L1130-R6JI1-FHA2	009-005RP	007-007RP	0010-012RP	0011-027RP	0012-021RP	
L1130-R6J12-FHA2						
L1130-Y6CD1-FHAN	009-005RP	007-007RP	009-029RP	0011-009RP	NA	
L1130-Y6CF1-FHA1	009-005RP	007-007RP	009-035RP	0011-009RP	0012-021RP	
L1130-Y6CF1-FHAN	009-005RP	007-007RP	009-035RP	0011-009RP	0011-023RP	
L1130-Y6CI1-FHA1	009-005RP	007-007RP	009-018RP	0011-009RP	0012-021RP	
L1130-Y6CI1-FHAN	009-005RP	007-007RP	009-018RP	0011-009RP	0011-023RP	
L1130-Y6CS1-FHAN	009-005RP	007-007RP	009-018RP	0011-009RP	NA	
L1130-Y6CV1-FHA1	009-005RP	007-007RP	009-029RP	0011-009RP	0012-021RP	
L1130-Y6CV1-FHAN	009-005RP	007-007RP	009-029RP	0011-009RP	0011-023RP	
L1130-Y6CX1-FHA1	009-005RP	007-007RP	009-034RP	0011-009RP	0012-021RP	
L1130-Y6CX1-FHAN	009-005RP	007-007RP	009-024RP	0011-009RP	0011-023RP	
L1130-Y6JI1-FHA2	009-005RP	007-007RP	009-002RP	0011-010RP	0012-021RP	
L1130-Y6SI1-FHAN	009-005RP	007-007RP	009-018RP	0011-010RP	0012-021RP	
L1130-Y6SS1-FHAN	009-005RP	007-007RP	009-018RP	0011-010RP	NA	
L1130-Y6SV1-FHAN	009-005RP	007-007RP	009-029RP	0011-010RP	0012-021RP	

L1614-

Pump Model Number	Casing O-Ring	Flange Gasket Set	Capacitor /PC Board	Cartridge Assembly	Flow Check	Relay
L1614-B5CI1-FHAN	0012-006RP	0012-020RP	0010-012RP	0012-011RP	0012-021RP	
L1614-B6CI1-FHAN	0012-006RP	0012-020RP	0010-012RP	0012-011RP	0012-021RP	
L1614-B6SI1-FHAN	0012-006RP	0012-020RP	0010-012RP	0012-012RP	0012-021RP	
L1614-R6CI1-FHAN	0012-006RP	0012-020RP	0012-012RP	0012-024RP	0012-021RP	
L1614-R6CI2-FHAN	0012-006RP	0012-020RP	0012-012RP	0012-026RP	0012-021RP	
L1614-R6SS2-FVA1	0012-006RP	1400-009RP	009-018RP	0012-012RP		
L1614-Y6CI1-FHAN	0012-006RP	0012-020RP	009-018RP	0012-011RP	0012-021RP	
L1614-Y6CS1-FVAN	0012-006RP	0012-020RP	009-018RP	0012-011RP	NA	
L1614-Y6CV1-FHAN	0012-006RP	0012-020RP	009-029RP	0012-011RP	0012-021RP	
L1614-Y6CX1-FHA1	0012-006RP	0012-020RP	009-034RP	0012-011RP	0012-021RP	
L1614-Y6CX1-FHAN	0012-006RP	0012-020RP	009-024RP	0012-011RP	0012-021RP	
L1614-Y6SI1-FHAN	0012-006RP	0012-020RP	009-018RP	0012-012RP	0012-021RP	
L1614-Y6SI1-FVA1	0012-006RP	1400-009RP	009-018RP	0012-012RP	0012-021RP	
L1614-Y6SS1-FVA1	0012-006RP	1400-009RP	009-018RP	0012-012RP		
L1614-Y6SV1-FHAN	0012-006RP	0012-020RP	009-029RP	0012-012RP	0012-021RP	